


# OPEN GENTLY



1



2



3







4

## HOW TO SET UP THE GAZEBO

Follow these instructions carefully to avoid catching your fingers in any of the moving parts as the frame opens and closes. We recommend having two persons to set up the gazebo.

1. Place your fold up gazebo in the centre of the area to be sheltered. Remove the carry bag and stand the fold up gazebo on its feet. With 1 person on the opposite side, hold onto the two outer legs, slightly lift the frame off the ground and take a step backwards, stepping at full (outstretched) arm's length.
2. Each partner should grasp the top and bottom of the diamond (see diagram) formed by the side supports and opposite sides and push hands together while stepping backwards until the canopy is fully open. Be careful not to pinch your fingers or to pull backwards too hard as this will result in the side supports bending.
3. Engage the slider at each corner by pushing up with one hand while holding down the top of the leg with the other hand (see diagram). Repeat this operation on the remaining three legs.
4. You and your partner should each place a foot on the foot plate of the bottom of adjacent legs and lift up the leg, sliding the inner leg out until the snap button engages into the locating hole. Repeat this operation for the other two legs. Square up the gazebo and attach the velcro tabs located on the underside of the top cover around the frame. Use the guy ropes attached to the ring at each corner of the roof cover and stakes to secure your gazebo to the ground by pushing the stakes through the hole for each foot.

# CLOSE GENTLY



## HOW TO TAKE DOWN THE GAZEBO

### CAUTION:

Do not attempt to take down the gazebo in windy conditions as it can be dangerous and could result in injury or cause damage to the product. To take down the gazebo would require two persons.

5. Remove any leg stakes and guy ropes; undo the velcro of the top cover from around the frame. You and your partner should each lift up two adjacent outer legs slightly, press the snap button and push the telescopic inner legs into the outer legs. Repeat for the remaining two legs.

6. Release the slider at all four corners by a slight upward pressure with one hand while pressing the snap button to release the slider.

7. Each partner should hold the top of the diamond (see diagram) on opposite sides and slightly lift up. Shake the canopy a little pull hands apart while stepping towards your partner until the unit is three quarters closed.

8. Hold onto the two outer legs, slightly lift off the ground and push to get the gazebo to fully close.

Before storing away your gazebo, make sure the canopy is completely dry.

This is not a permanent fixture, and should be taken down after use.